

# Task for first week

## 1.- Reading materials:

Understanding DNA: The Molecule and How it Works. Authors: Chris Calladine, Horace Drew, Ben Luisi, Andrew Travers.

## 2.- LAMMPS installation with oxDNA:

Instructions are provided in the additional pdf file: **README/lammpsinstallation.pdf**

LAMMPS scripts and simple initial configuration can be found in the LAMMPS folder: *examples/PACKAGES/cgdna/examples/oxDNA2/*. There, you will see examples of double stranded rings (inside dsring) or linear double stranded DNA (inside duplex1).

## 3.-oxView

a) Read the description of oxView on their github site: <https://github.com/sulcgroup/oxdna-viewer>

b) Watch their youtube tutorial: <https://www.youtube.com/watch?v=arhmT0LStUQ>

c) Use the website tool of oxview <https://sulcgroup.github.io/oxdna-viewer/> to create your own initial configuration of a linear double-stranded DNA with the following sequence:

AACGGAATTTCGCATGGATCCCCACGATCG

Save that configuration as an oxDNA type. This will create two files (usually on your *Downloads* folder) called: **output.top** (this is the topology files with information about the bonds) and **output.dat** (thi is the file with the positions and orientations of the nucleotides in your system).

## 4.-tacoxDNA

Convert the previous two files into a format that can be read by LAMMPS using tacoxDNA website: [http://tacoxdna.sissa.it/oxDNA\\_LAMMPS](http://tacoxdna.sissa.it/oxDNA_LAMMPS)

## 5.-Run and compare two simulations

a) Using the LAMMPS script mentioned in point 2, but with the initial configuration you created, run the simulation for at least  $2 \times 10^7$  timesteps. You have to modify a little bit the script for this:

Replace:

```
variable ofreq equal 1000  
variable efreq equal 1000  
read_data data.duplex1  
run 1000000
```

By the following:

```
variable ofreq equal 50000  
variable efreq equal 50000  
read_data NameOfYourInitialCongigurationFile  
run 20000000
```

Finally, chek the trajectory with vmd.

b) If you have enough time, create an initial configuration with the same sequence as before, but this time instead of creating a double-stranded DNA, create a single-stranded DNA. Run a simulation and check the thrajectory with VMD. Dou you notice any difference? which?

c) With oxview, try to create a ring double-stranded-DNA instead of a linear one.